

# Data sheet

# Servo-operated 2/2-way solenoid valves for high pressure Type EV224B



EV224B for compressed air, is a high pressure indirect servo-operated 2/2-way solenoid valve with working pressure up to 40 bar, medium temperature up to 60 °C and available in NC and NO versions.

Built-in pilot filter as standard, replaceable equalizing orifice, enclosures up to IP67 (depending on coil) ensure a reliable and satisfactory function.

#### Features

- For compressed air and compressed air with mineral oil
- Differential pressure: Up to 40 bar
- Ambient temperature: Up to 60 °C
- Media temperature from -10 60  $^\circ\mathrm{C}$
- · Coil enclosure: Up to IP67

- Thread connection: From  $G^{1/2} G^{1}$
- Built in filter for protection of pilot system
- NC and NO versions



## Brass valve body, NC



				Differential pressure, min. to max. [bar]				Min. burst			
				BE / BB	BE / BB	BG	Max. operating	Max. test	pressure acc.	Media temperature	
Connection ISO 228/1	Seal material	Orifice size	K <sub>v</sub> - value [m³/h]	18 [W DC]	10 [W AC]	12 [W AC], 20 [W DC]		pressure [bar]	EN 12516 [bar]	min. to max. [°C]	Code number
G 1⁄2	NBR	15	4	0.3 – 40	0.3 – 40	0.3 – 40	40	60	159	-10 - 60	032U8360
G 3⁄4	NBR	20	8	0.3 – 35	0.3 – 35	0.3 – 35	35	53	142	-10 - 60	032U8362
G 1	NBR	25	11	0.3 – 33	0.3 – 33	0.3 – 33	33	50	134	-10 - 60	032U8364

Used with synthetic oils, and with media temperature between 40 – 60  $^\circ$ C, life time can be reduced

# Brass valve body, NO



				Differentia	al pressure, r [bar]	nin. to max.			Min. burst		
				BE / BB	BE / BB	BG	Max. operating	Max. test	pressure acc.	Media temperature	
Connection ISO 228/1	Seal material	Orifice size	K <sub>v</sub> - value [m³/h]	18 [W DC]	10 [W AC]	12 [W AC], 20 [W DC]	pressure [bar]	pressure [bar]	EN 12516 [bar]	min. to max. [°C]	Code number
G 1⁄2	NBR	15	4	0.3 – 40	0.3 – 40	0.3 – 40	40	60	159	-10 - 60	032U8361
G 3⁄4	NBR	20	8	0.3 – 35	0.3 – 35	0.3 – 35	35	53	142	-10 - 60	032U8363
G 1	NBR	25	11	0.3 – 33	0.3 – 33	0.3 – 33	33	50	134	-10 - 60	032U8365

Used with synthetic oils, and with media temperature between 40 – 60 °C, life time can be reduced

#### **Technical data**

Туре	EV224B					
Installation	Vertical solenoid syst	em is recom	mended.			
Max. test pressure	64 bar					
	Coil type: BB	10 W AC /	18 W DC Up to 60 °C			
Ambient temperature	Coil type: BE	10 W AC /	18 W DC Up to 60 °C			
	Coil type: BG	12 W AC /	20 W DC	Up to 60 °C		
Viscosity	Max. 50 cSt					
Materials	Valve body:		Brass		W.no. 2.0402	
	Armature:		Stainless steel		W.no. 1.4105 / AISI 430FR	
	Armature tube:		Stainless steel		W.no. 1.4306 / AISI 304L	
	Armature stop:		Stainless steel		W.no. 1.4105 / AISI 430FR	
	Diaphragm valve cor	ne:	Stainless steel		W.no. 1.4404 / AISI 316L	
	Springs:		Stainless steel		W.no. 1.4310 / AISI 301	
	O-rings:		NBR		_	
Valve plate:			NC: NBR / NO: PTFE		_	
	Diaphragm:		NBR		-	




# Data sheet | Solenoid valves, type EV224B

# Dimensions and weight,


NC and NO

		В	B <sub>1</sub> [mm]	Coil type			Weight without
Туре	[mm]	в [mm]	BB / BE	BG	H [mm]	H₁ [mm]	coil [kg]
EV224B 15	80	52	46	68	99	15	0.8
EV224B 20	90	58	46	68	103	18	1.0
EV224B 25	109	70	46	68	113	22	1.4

#### Dimensions



# Mounting angle





# Below coils can be used with EV224B

Coil	Туре	Power consumption	Enclosure	Features
A DECEMBER OF	BB, clip on	AC: 11–16 W DC: 13–16 W	IP00 with spade connector	IP20 with protective cap, IP65 with cable plug
	BE, clip on	AC: 11–17 W DC: 13–15 W	IP67	With terminal box
	BG, clip-on	AC: 11–16 W DC: 16–20 W	IP67	With terminal box

Accessories: Cable plug




Application	Code number
GDM 2011 (grey) cable plug according to DIN 43650-A PG11	042N0156



# Data sheet | Solenoid valves, type EV224B

### Spare parts kit, NC



	Туре	Seal material	Code number
I	EV224B 15	NBR	032U6156
I	EV224B 20	NBR	032U6158
I	EV224B 25	NBR	032U6160

# The kit contains:

- O-ring for coil
- Armature tube assembly
- Armature with valve plate and spring
- O-ring for the armature tube
- 2 O-rings for the equalizing orifice
- Closing spring
- Diaphragm
- 2 O-rings for the pilot system



# Spare parts kit, NO

The second
BLa P

Spare parts kit for synthetic oil, NC/NO

Туре	Seal material	Code number
EV224B 15	NBR	032U6157
EV224B 20	NBR	032U6159
EV224B 25	NBR	032U6161

# The kit contains:

- O-ring for coil
- Armature unit assembly
- O-ring for the armature unit
- 2 O-rings for the equalizing orifice
- Closing spring
- Diaphragm
- 2 O-rings for the pilot system



Туре	Seal material	Code number	The kit contains:
EV224B 15	FKM	032U8118	<ul><li>Closing spring</li><li>Diaphragm</li></ul>
EV224B 20	FKM	032U8119	<ul> <li>2 O-rings for the pilot system</li> </ul>

ം






# ENGINEERING TOMORROW

# Danfoss

#### Function, NC



- 4. Pilot orifice
- 5. Diaphragm
- 6. Main orifice
- 7. Equalizing orifice



# Coil voltage disconnected (closed):

When the voltage is disconnected, the valve plate (3) is pressed down against the pilot orifice (4) by the armature spring (2). The pressure across the diaphragm (5) is built up via the equalizing orifice (7). The diaphragm closes the main orifice (6) as soon as the pressure across the diaphragm is equivalent to the inlet pressure. The valve will be closed for as long as the voltage to the coil is disconnected.


# Coil voltage connected (open):

When voltage is applied to the coil (1), the pilot orifice (4) is opened. As the pilot orifice is larger than the equalizing orifice (7), the pressure across the diaphragm (5) drops and therefore it is lifted clear of the main orifice (6). The valve is now open for unimpeded flow and will be open for as long as the minimum differential pressure across the valve is maintained, and for as long as there is voltage to the coil.

# Function, NO

Coil
 Armature spring
 Valve plate
 Pilot orifice
 Diaphragm
 Main orifice

7. Equalizing orifice



#### Coil voltage disconnected (open):

When the voltage to the coil (2) is disconnected, the pilot orifice (4) is open. As the pilot orifice is larger than the equalizing orifice (7), the pressure across the diaphragm (5) drops and therefore it is lifted clear of the main orifice (6). The valve will be open for as long as the minimum differential pressure across the valve is maintained, and for as long as the voltage to the coil is disconnected.

# Coil voltage connected (closed):

When voltage is applied to the coil, the valve plate (3) is pressed down against the pilot orifice (4). The pressure across the diaphragm (5) is built up via the equalizing orifice (7). The diaphragm closes the main orifice (6) as soon as the pressure across the diaphragm is equivalent to the inlet pressure. The valve will be closed for as long as there is voltage to the coil.

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.